

8W-50 FRONT LIGHTING

Component	Page	Component	Page
Clearance Lamp No. 1	8W-50-6	G104	8W-50-3, 4, 5
Clearance Lamp No. 2	8W-50-6	G105	8W-50-3, 4
Clearance Lamp No. 3	8W-50-6	G201	8W-50-5
Clearance Lamp No. 4	8W-50-6	G202	8W-50-6
Clearance Lamp No. 5	8W-50-6	Headlamp Switch	8W-50-2, 5
Data Link Connector	8W-50-2	Headlamp-Left	8W-50-3
Fog Lamp Relay	8W-50-5	Headlamp-Right	8W-50-3
Fog Lamp-Left	8W-50-5	Instrument Cluster	8W-50-2, 5
Fog Lamp-Right	8W-50-5	Integrated Power Module	8W-50-2, 3, 4, 5
Front Control Module	8W-50-2, 3, 4, 5	Multi-Function Switch	8W-50-2
Fuse 15	8W-50-4	Park Lamp Relay	8W-50-4
Fuse 32	8W-50-4	Park/Turn Signal Lamp-Left Front	8W-50-4
Fuse 34	8W-50-4	Park/Turn Signal Lamp-Right Front	8W-50-4
Fuse 41	8W-50-5		









